

SOUNDBOKS GO

Wherever you go, however you go, whatever you're going to do - SOUNDBOKS Go makes your music go too. This is a Bluetooth Performance Speaker, only smaller. Still powerful, durable, and truly portable with our incredible swappable battery and sound beyond its size.

Experience the latest in concert-level sound and performance from SOUNDBOKS.



PERFORMANCE FOR EVERY DAY

Sound, battery + capability means true Bluetooth Performance on the Go. Get concert-level experiences wherever you are with SOUNDBOKS Bass Enhancer, customizable sound profiles, and up to 10hrs of playtime at full volume.

PORTABILITY FOR EVERYONE

Packable, tossable, swingable + totable. The Go fits in the backseat, on a bike rack and over your shoulder for portability unlike any other SOUNDBOKS. You don't even need the backpack.




DYNAMIC TO YOU

Enter the world of SOUNDBOKS with Bluetooth Performance that fits into your vibe and lifestyle. Access the world of SOUNDBOKS and TeamUp with friends, so you can find your frequency and Go.

DESIGNED TO BREAK THROUGH

Dentproof, splashproof + lightweight with reinforced unibody cabinet. Futureproof with access to performance and sound upgrades through the app that give you a whole new SOUNDBOKS from the inside out.


EASY SET-UP




01 Charge your BATTERYBOKS fully for ~3.5 hours for optimal performance.
02 Once charged, slide (don't force) your BATTERYBOKS LED-side-down until it fits snugly into the battery slot. Then plug in the DC connector.



Never plug the charger directly into your speaker without the battery.



03 The charger T-jack was designed to be used while playing at moderate volumes, but the charger is not a power supply. Keep your SOUNDBOKS under half volume—12 o'clock on the dial with 5 lights illuminated—when playing and charging simultaneously.



04 Power up your speaker by firmly pressing the volume knob. When the LEDs around the volume knob light up, you're ready to connect.

05 To connect, go to your device's Bluetooth settings, find and select SOUNDBOKS #YourTeamID. Your unique Team ID is located on the left side of your speaker.
06 Choose your favorite song, turn up, go out and Break Through the Noise.



Connect to the SOUNDBOKS App for more sounds, more control, more security and more SOUNDBOKS.

SOUNDBOKS