



1


Level the mount and mark.




Drill the mounting holes.




Insert the wall anchors\* to the wall and tap them flush with a hammer.  
\* Never use wall anchors on drywall




Fix the plate to the wall.





Attach the mounting rails to screen.  
- Ensure that each rail mounting slot is facing down.  
- Use the selected screws and washers to mount the rail to screen.




Tightly secure the mounting screws.



Mount screen to the wall.



x1



5


x2



6


x4

M8



2

x4



3


x4



4

x4


M5



4

x4


M6



4

x4

M8



x4

M5



x4

M6

**SONOROUS**  
SOUND AND VISION IN STYLE